

✓ Know How to Measure Your Windows for Window Guard Selection:
(When children are *not* present) Open the window to the widest point and measure the opening.

For Casement or Sliding Windows: Guards are installed vertically (bars go up and down)

- 1) Measure from the top of the window frame to the bottom of the window frame. (Measure part of the window that is open not the glass portion of the window).
- 2) Next, measure from the side of the window frame to the edge of the window opening (area that is usually covered by the screen)

To measure Sliding or Casement Style Windows:



Measure Height for Sliding or Casement Windows



Measure Width of Sliding or Casement Windows

To Measure Single or Double Hung Windows: Guards are installed horizontally (bars go side to side).

- 1) Measure from one side of the window frame to the other side of the frame.
- 2) Next measure from the bottom of the window opening to the top of the opening.

To Measure Single or Double Hung Windows:



Measure Height Single or Double Hung Windows



Measure Width of Single or Double Hung Windows